
LwGPS

Tilen MAJERLE

Sep 24, 2020

CONTENTS

1	Features	3
2	Requirements	5
3	Contribute	7
4	License	9
5	Table of contents	11
5.1	Getting started	11
5.2	User manual	14
5.3	API reference	17
5.4	Examples and demos	24
	Index	29

Welcome to the documentation for version latest-develop.

LwGPS is lightweight, platform independent library to parse NMEA statements from GPS receivers. It is highly optimized for embedded systems.

[Download library](#) [Getting started](#) [Open Github](#)

FEATURES

- Written in ANSI C99
- Platform independent, easy to use
- Built-in support for 4 GPS statements
 - GPGGA or GNGGA: GPS fix data
 - GPGSA or GNGSA: GPS active satellites and dillusion of position
 - GPGSV or GNGSV: List of satellites in view zone
 - GPRMC or GNRMC: Recommended minimum specific GPS/Transit data
- Optional `float` or `double` floating point units
- Low-level layer is separated from application layer, thus allows you to add custom communication with GPS device
- Works with operating systems
- Works with different communication interfaces
- User friendly MIT license

REQUIREMENTS

- C compiler
- Driver for receiving data from GPS receiver
- Few *kB* of non-volatile memory

CONTRIBUTE

Fresh contributions are always welcome. Simple instructions to proceed:

1. Fork Github repository
2. Respect `C style & coding rules` used by the library
3. Create a pull request to `develop` branch with new features or bug fixes

Alternatively you may:

1. Report a bug
2. Ask for a feature request

LICENSE

MIT License

Copyright (c) 2020 Tilen MAJERLE

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to **do** so, subject to the following **conditions**:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

TABLE OF CONTENTS

5.1 Getting started

5.1.1 Download library

Library is primarily hosted on [Github](#).

- Download latest release from [releases area](#) on Github
- Clone *develop* branch for latest development

Download from releases

All releases are available on Github [releases area](#).

Clone from Github

First-time clone

- Download and install `git` if not already
- Open console and navigate to path in the system to clone repository to. Use command `cd your_path`
- Clone repository with one of available 3 options
 - Run `git clone --recurse-submodules https://github.com/MaJerle/lwgps` command to clone entire repository, including submodules
 - Run `git clone --recurse-submodules --branch develop https://github.com/MaJerle/lwgps` to clone *development* branch, including submodules
 - Run `git clone --recurse-submodules --branch master https://github.com/MaJerle/lwgps` to clone *latest stable* branch, including submodules
- Navigate to `examples` directory and run favourite example

Update cloned to latest version

- Open console and navigate to path in the system where your resources repository is. Use command `cd your_path`
- Run `git pull origin master --recurse-submodules` command to pull latest changes and to fetch latest changes from submodules
- Run `git submodule foreach git pull origin master` to update & merge all submodules

Note: This is preferred option to use when you want to evaluate library and run prepared examples. Repository consists of multiple submodules which can be automatically downloaded when cloning and pulling changes from root repository.

5.1.2 Add library to project

At this point it is assumed that you have successfully download library, either cloned it or from releases page.

- Copy `lwgps` folder to your project
- Add `lwgps/src/include` folder to *include path* of your toolchain
- Add source files from `lwgps/src/` folder to toolchain build
- Copy `lwgps/src/include/lwgps/lwgps_opts_template.h` to project folder and rename it to `lwgps_opts.h`
- Build the project

5.1.3 Configuration file

Library comes with template config file, which can be modified according to needs. This file shall be named `lwgps_opts.h` and its default template looks like the one below.

Note: Default configuration template file location: `lwgps/src/include/lwgps/lwgps_opts_template.h`. File must be renamed to `lwgps_opts.h` first and then copied to the project directory (or simply renamed in-place) where compiler include paths have access to it by using `#include "lwgps_opts.h"`.

Tip: Check *Configuration* section for possible configuration settings

Listing 1: Template options file

```
1  /**
2   * \file          lwgps_opts_template.h
3   * \brief        LwGPS configuration file
4   */
5
6  /**
7   * Copyright (c) 2020 Tilen MAJERLE
8   *
9   * Permission is hereby granted, free of charge, to any person
```

(continues on next page)

(continued from previous page)

```

10  * obtaining a copy of this software and associated documentation
11  * files (the "Software"), to deal in the Software without restriction,
12  * including without limitation the rights to use, copy, modify, merge,
13  * publish, distribute, sublicense, and/or sell copies of the Software,
14  * and to permit persons to whom the Software is furnished to do so,
15  * subject to the following conditions:
16  *
17  * The above copyright notice and this permission notice shall be
18  * included in all copies or substantial portions of the Software.
19  *
20  * THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND,
21  * EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES
22  * OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE
23  * AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT
24  * HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY,
25  * WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING
26  * FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR
27  * OTHER DEALINGS IN THE SOFTWARE.
28  *
29  * This file is part of LwGPS - Lightweight GPS NMEA parser library.
30  *
31  * Author:          Tilen MAJERLE <tilen@majerle.eu>
32  * Version:         $_version_$
33  */
34 #ifndef LWGPS_HDR_OPTS_H
35 #define LWGPS_HDR_OPTS_H
36
37 /* Rename this file to "lwgps_opts.h" for your application */
38
39 /*
40  * Open "include/lwgps/lwgps_opt.h" and
41  * copy & replace here settings you want to change values
42  */
43
44 #endif /* LWGPS_HDR_OPTS_H */

```

5.1.4 Minimal example code

Run below example to test and verify library

Listing 2: Test verification code

```

1  /**
2   * This example uses direct processing function
3   * to process dummy NMEA data from GPS receiver
4   */
5  #include <string.h>
6  #include <stdio.h>
7  #include "lwgps/lwgps.h"
8
9  /* GPS handle */
10 lwgps_t hgps;
11
12 /**
13  * \brief          Dummy data from GPS receiver

```

(continues on next page)

```

14  */
15  const char
16  gps_rx_data[] = ""
17          "$GPRMC,183729,A,3907.356,N,12102.482,W,000.0,360.0,080301,015.5,E*6F\
↳r\n"
18          "$GPRMB,A,,,,,,,,,,,,,V*71\r\n"
19          "$GPGGA,183730,3907.356,N,12102.482,W,1,05,1.6,646.4,M,-24.1,M,,*75\r\
↳n"
20          "$GPGSA,A,3,02,,,07,,09,24,26,,,,,1.6,1.6,1.0*3D\r\n"
21          "$GPGSV,2,1,08,02,43,088,38,04,42,145,00,05,11,291,00,07,60,043,35*71\
↳r\n"
22          "$GPGSV,2,2,08,08,02,145,00,09,46,303,47,24,16,178,32,26,18,231,43*77\
↳r\n"
23          "$PGRME,22.0,M,52.9,M,51.0,M*14\r\n\r\n"
24          "$GPGLL,3907.360,N,12102.481,W,183730,A*33\r\n"
25          "$PGRMZ,2062,f,3*2D\r\n"
26          "$PGRMM,WGS84*06\r\n"
27          "$GPBOD,,T,,M,,*47\r\n"
28          "$GPRTE,1,1,c,0*07\r\n"
29          "$GPRMC,183731,A,3907.482,N,12102.436,W,000.0,360.0,080301,015.5,E*67\
↳r\n"
30          "$GPRMB,A,,,,,,,,,,,,,V*71\r\n";
31
32  int
33  main() {
34      /* Init GPS */
35      lwgps_init(&hgps);
36
37      /* Process all input data */
38      lwgps_process(&hgps, gps_rx_data, strlen(gps_rx_data));
39
40      /* Print messages */
41      printf("Valid status: %d\r\n", hgps.is_valid);
42      printf("Latitude: %f degrees\r\n", hgps.latitude);
43      printf("Longitude: %f degrees\r\n", hgps.longitude);
44      printf("Altitude: %f meters\r\n", hgps.altitude);
45
46      return 0;
47  }

```

5.2 User manual

5.2.1 How it works

LwGPS parses raw data formatted as NMEA 0183 statements from GPS receivers. It supports up to 4 different statements:

- GPGGA or GNGGA: GPS fix data
- GPGSA or GNGSA: GPS active satellites and dilution of position
- GPGSV or GNGSV: List of satellites in view zone
- GPRMC or GNRMC: Recommended minimum specific GPS/Transit data

Tip: By changing different configuration options, it is possible to disable some statements. Check *Configuration* for more information.

Application must assure to properly receive data from GPS receiver. Usually GPS receivers communicate with host embedded system with UART protocol and output directly formatted NMEA 0183 statements.

Note: Application must take care of properly receive data from GPS.

Application must use `lwgps_process()` function for data processing. Function will:

- Detect statement type, such as *GPGGA* or *GPGSV*
- Parse all the terms of specific statement
- Check valid CRC after each statement

Programmer's model is as following:

- Application receives data from GPS receiver
- Application sends data to `lwgps_process()` function
- Application uses processed data to display altitude, latitude, longitude, and other parameters

Check *Examples and demos* for typical example

5.2.2 Float/double precision

With configuration of `GSM_CFG_DOUBLE`, it is possible to enable `double` floating point precision. All floating point variables are then configured in *double precision*.

When configuration is set to 0, floating point variables are configured in *single precision* format.

Note: Single precision uses less memory in application. As a drawback, application may be a subject of data loss at latter digits.

5.2.3 Thread safety

Library tends to be as simple as possible. No specific features have been implemented for thread safety.

When library is using multi-thread environment and if multi threads tend to access to shared resources, user must resolve it with care, using mutual exclusion.

Tip: When single thread is dedicated for GPS processing, no special mutual exclusion is necessary.

5.2.4 Tests during development

During the development, test check is performed to validate raw NMEA input data vs expected result.

Listing 3: Test code for development

```

1  /*
2   * This example uses direct processing function,
3   * to process dummy NMEA data from GPS receiver
4   */
5  #include <string.h>
6  #include <stdio.h>
7  #include "lwgps/lwgps.h"
8  #include "test_common.h"
9
10 /* GPS handle */
11 lwgps_t hgps;
12
13 /**
14  * \brief      Dummy data from GPS receiver
15  */
16 const char
17 gps_rx_data[] = ""
18                "$GPRMC,183729,A,3907.356,N,12102.482,W,000.0,360.0,080301,015.5,E*6F\
↳r\n"
19                "$GPGGA,183730,3907.356,N,12102.482,W,1,05,1.6,646.4,M,-24.1,M,,*75\r\
↳n"
20                "$GPGSA,A,3,02,,,07,,09,24,26,,,,,1.6,1.6,1.0*3D\r\n"
21                "$GPGSV,2,1,08,02,43,088,38,04,42,145,00,05,11,291,00,07,60,043,35*71\
↳r\n"
22                "$GPGSV,2,2,08,08,02,145,00,09,46,303,47,24,16,178,32,26,18,231,43*77\
↳r\n"
23                "";
24
25 /**
26  * \brief      Run the test of raw input data
27  */
28 void
29 run_tests() {
30     lwgps_init(&hgps);                /* Init GPS */
31
32     /* Process all input data */
33     lwgps_process(&hgps, gps_rx_data, strlen(gps_rx_data));
34
35     /* Run the test */
36     RUN_TEST(!INT_IS_EQUAL(hgps.is_valid, 0));
37     RUN_TEST(INT_IS_EQUAL(hgps.fix, 1));
38     RUN_TEST(INT_IS_EQUAL(hgps.fix_mode, 3));
39     RUN_TEST(FLT_IS_EQUAL(hgps.latitude, 39.1226000000));
40     RUN_TEST(FLT_IS_EQUAL(hgps.longitude, -121.0413666666));
41     RUN_TEST(FLT_IS_EQUAL(hgps.altitude, 646.4000000000));
42     RUN_TEST(FLT_IS_EQUAL(hgps.course, 360.0000000000));
43     RUN_TEST(INT_IS_EQUAL(hgps.dop_p, 1.6000000000));
44     RUN_TEST(INT_IS_EQUAL(hgps.dop_h, 1.6000000000));
45     RUN_TEST(INT_IS_EQUAL(hgps.dop_v, 1.0000000000));
46     RUN_TEST(FLT_IS_EQUAL(hgps.speed, 0.0000000000));
47     RUN_TEST(FLT_IS_EQUAL(hgps.geo_sep, -24.1000000000));
48     RUN_TEST(FLT_IS_EQUAL(hgps.variation, 15.5000000000));

```

(continues on next page)

(continued from previous page)

```
49  RUN_TEST(INT_IS_EQUAL(hgps.sats_in_view, 8));
50
51  RUN_TEST(INT_IS_EQUAL(hgps.sats_in_use, 5));
52  RUN_TEST(INT_IS_EQUAL(hgps.satellites_ids[0], 2));
53  RUN_TEST(INT_IS_EQUAL(hgps.satellites_ids[1], 0));
54  RUN_TEST(INT_IS_EQUAL(hgps.satellites_ids[2], 0));
55  RUN_TEST(INT_IS_EQUAL(hgps.satellites_ids[3], 7));
56  RUN_TEST(INT_IS_EQUAL(hgps.satellites_ids[4], 0));
57  RUN_TEST(INT_IS_EQUAL(hgps.satellites_ids[5], 9));
58  RUN_TEST(INT_IS_EQUAL(hgps.satellites_ids[6], 24));
59  RUN_TEST(INT_IS_EQUAL(hgps.satellites_ids[7], 26));
60  RUN_TEST(INT_IS_EQUAL(hgps.satellites_ids[8], 0));
61  RUN_TEST(INT_IS_EQUAL(hgps.satellites_ids[9], 0));
62  RUN_TEST(INT_IS_EQUAL(hgps.satellites_ids[10], 0));
63  RUN_TEST(INT_IS_EQUAL(hgps.satellites_ids[11], 0));
64
65  RUN_TEST(INT_IS_EQUAL(hgps.date, 8));
66  RUN_TEST(INT_IS_EQUAL(hgps.month, 3));
67  RUN_TEST(INT_IS_EQUAL(hgps.year, 1));
68  RUN_TEST(INT_IS_EQUAL(hgps.hours, 18));
69  RUN_TEST(INT_IS_EQUAL(hgps.minutes, 37));
70  RUN_TEST(INT_IS_EQUAL(hgps.seconds, 30));
71 }
```

5.3 API reference

List of all the modules:

5.3.1 LwGPS

group **LWGPS**

Lightweight GPS NMEA parser.

Defines

lwgps_is_valid(*_gh*)

Check if current GPS data contain valid signal.

Note *LWGPS_CFG_STATEMENT_GPRMC* must be enabled and GPRMC statement must be sent from GPS receiver

Return 1 on success, 0 otherwise

Parameters

- [*in*] *_gh*: GPS handle

Typedefs

typedef double **lwgps_float_t**
GPS float definition, can be either `float` or `double`

Note Check for `LWGPS_CFG_DOUBLE` configuration

typedef void (***lwgps_process_fn**) (*lwgps_statement_t* res)
Signature for caller-supplied callback function from `gps_process`.

Parameters

- [in] `res`: statement type of recently parsed statement

Enums

enum **lwgps_statement_t**
ENUM of possible GPS statements parsed.

Values:

enumerator **STAT_UNKNOWN**
Unknown NMEA statement

enumerator **STAT_GGA**
GPGGA statement

enumerator **STAT_GSA**
GPGSA statement

enumerator **STAT_GSV**
GPGSV statement

enumerator **STAT_RMC**
GPRMC statement

enumerator **STAT_UBX**
UBX statement (uBlox specific)

enumerator **STAT_UBX_TIME**
UBX TIME statement (uBlox specific)

enumerator **STAT_CHECKSUM_FAIL**
Special case, used when checksum fails

enum **lwgps_speed_t**
List of optional speed transformation from GPS values (in knots)

Values:

enumerator **lwgps_speed_kps**
Kilometers per second

enumerator **lwgps_speed_kph**
Kilometers per hour

enumerator **lwgps_speed_mps**
Meters per second

enumerator **lwgps_speed_mpm**
Meters per minute

enumerator `lwgps_speed_mips`
Miles per second

enumerator `lwgps_speed_mph`
Miles per hour

enumerator `lwgps_speed_fps`
Footing per second

enumerator `lwgps_speed_fpm`
Footing per minute

enumerator `lwgps_speed_mpk`
Minutes per kilometer

enumerator `lwgps_speed_spk`
Seconds per kilometer

enumerator `lwgps_speed_sp100m`
Seconds per 100 meters

enumerator `lwgps_speed_mipm`
Minutes per mile

enumerator `lwgps_speed_spm`
Seconds per mile

enumerator `lwgps_speed_sp100y`
Seconds per 100 yards

enumerator `lwgps_speed_smph`
Sea miles per hour

Functions

`uint8_t lwgps_init (lwgps_t *gh)`
Init GPS handle.

Return 1 on success, 0 otherwise

Parameters

- [in] `gh`: GPS handle structure

`uint8_t lwgps_process (lwgps_t *gh, const void *data, size_t len, lwgps_process_fn evt_fn)`
Process NMEA data from GPS receiver.

Return 1 on success, 0 otherwise

Parameters

- [in] `gh`: GPS handle structure
- [in] `data`: Received data
- [in] `len`: Number of bytes to process
- [in] `evt_fn`: Event function to notify application layer. This parameter is available only if `LWGPS_CFG_STATUS` is enabled

`uint8_t lwgps_distance_bearing` (*lwgps_float_t las, lwgps_float_t los, lwgps_float_t lae, lwgps_float_t loe, lwgps_float_t *d, lwgps_float_t *b*)

Calculate distance and bearing between 2 latitude and longitude coordinates.

Return 1 on success, 0 otherwise

Parameters

- [in] `las`: Latitude start coordinate, in units of degrees
- [in] `los`: Longitude start coordinate, in units of degrees
- [in] `lae`: Latitude end coordinate, in units of degrees
- [in] `loe`: Longitude end coordinate, in units of degrees
- [out] `d`: Pointer to output distance in units of meters
- [out] `b`: Pointer to output bearing between start and end coordinate in relation to north in units of degrees

lwgps_float_t `lwgps_to_speed` (*lwgps_float_t sik, lwgps_speed_t ts*)

Convert NMEA GPS speed (in knots = nautical mile per hour) to different speed format.

Return Speed calculated from knots

Parameters

- [in] `sik`: Speed in knots, received from GPS NMEA statement
- [in] `ts`: Target speed to convert to from knots

struct `lwgps_sat_t`

#include <lwgps.h> Satellite descriptor.

Public Members

`uint8_t num`

Satellite number

`uint8_t elevation`

Elevation value

`uint16_t azimuth`

Azimuth in degrees

`uint8_t snr`

Signal-to-noise ratio

struct `lwgps_t`

#include <lwgps.h> GPS main structure.

Public Members

lwgps_float_t **latitude**

Latitude in units of degrees

lwgps_float_t **longitude**

Longitude in units of degrees

lwgps_float_t **altitude**

Altitude in units of meters

lwgps_float_t **geo_sep**

Geoid separation in units of meters

uint8_t sats_in_use

Number of satellites in use

uint8_t fix

Fix status. 0 = invalid, 1 = GPS fix, 2 = DGPS fix, 3 = PPS fix

uint8_t hours

Hours in UTC

uint8_t minutes

Minutes in UTC

uint8_t seconds

Seconds in UTC

lwgps_float_t **dop_h**

Dolution of precision, horizontal

lwgps_float_t **dop_v**

Dolution of precision, vertical

lwgps_float_t **dop_p**

Dolution of precision, position

uint8_t fix_mode

Fix mode. 1 = NO fix, 2 = 2D fix, 3 = 3D fix

uint8_t satellites_ids[12]

List of satellite IDs in use. Valid range is 0 to `sats_in_use`

uint8_t sats_in_view

Number of satellites in view

lwgps_sat_t **sats_in_view_desc[12]**

uint8_t is_valid

GPS valid status

lwgps_float_t **speed**

Ground speed in knots

lwgps_float_t **course**

Ground coarse

lwgps_float_t **variation**

Magnetic variation

uint8_t date

Fix date

`uint8_t month`
Fix month

`uint8_t year`
Fix year

lwgps_float_t `utc_tow`
UTC TimeOfWeek, eg 113851.00

`uint16_t utc_wk`
UTC week number, continues beyond 1023

`uint8_t leap_sec`
UTC leap seconds; UTC + leap_sec = TAI

`uint32_t clk_bias`
Receiver clock bias, eg 1930035

lwgps_float_t `clk_drift`
Receiver clock drift, eg -2660.664

`uint32_t tp_gran`
Time pulse granularity, eg 43

5.3.2 Configuration

This is the default configuration of the middleware. When any of the settings shall be modified, it shall be done in dedicated application config `lwgps_opts.h` file.

Note: Check *Getting started* to create configuration file.

group **LWGPS_OPT**
Default configuration setup.

Defines

LWGPS_CFG_DOUBLE

Enables 1 or disables 0 `double` precision for floating point values such as latitude, longitude, altitude.

`double` is used as variable type when enabled, `float` when disabled.

LWGPS_CFG_STATUS

Enables 1 or disables 0 status reporting callback by *lwgps_process*.

Note This is an extension, so not enabled by default.

LWGPS_CFG_STATEMENT_GPGGA

Enables 1 or disables 0 GGA statement parsing.

Note This statement must be enabled to parse:

- Latitude, Longitude, Altitude
- Number of satellites in use, fix (no fix, GPS, DGPS), UTC time

LWGPS_CFG_STATEMENT_GPGSA

Enables 1 or disables 0 GSA statement parsing.

Note This statement must be enabled to parse:

- Position/Vertical/Horizontal dilution of precision
- Fix mode (no fix, 2D, 3D fix)
- IDs of satellites in use

LWGPS_CFG_STATEMENT_GPRMC

Enables 1 or disables 0 RMC statement parsing.

Note This statement must be enabled to parse:

- Validity of GPS signal
- Ground speed in knots and course in degrees
- Magnetic variation
- UTC date

LWGPS_CFG_STATEMENT_GPGSV

Enables 1 or disables 0 GSV statement parsing.

Note This statement must be enabled to parse:

- Number of satellites in view
- Optional details of each satellite in view. See [LWGPS_CFG_STATEMENT_GPGSV_SAT_DET](#)

LWGPS_CFG_STATEMENT_GPGSV_SAT_DET

Enables 1 or disables 0 detailed parsing of each satellite in view for GSV statement.

Note When this feature is disabled, only number of “satellites in view” is parsed

LWGPS_CFG_STATEMENT_PUBX

Enables 1 or disables 0 parsing and generation of PUBX (uBlox) messages.

PUBX are a nonstandard ublox-specific extensions, so disabled by default.

LWGPS_CFG_STATEMENT_PUBX_TIME

Enables 1 or disables 0 parsing and generation of PUBX (uBlox) TIME messages.

This is a nonstandard ublox-specific extension, so disabled by default.

Note TIME messages can be used to obtain:

- UTC time of week
- UTC week number
- Leap seconds (allows conversion to eg. TAI)

This configure option requires LWGPS_CFG_STATEMENT_PUBX

5.4 Examples and demos

There are several basic examples provided with the library.

5.4.1 Parse block of data

In this example, block of data is prepared as big string array and sent to processing function in single shot. Application can then check if GPS signal has been detected as valid and use other data accordingly.

Listing 4: Minimum example code

```

1  /**
2   * This example uses direct processing function
3   * to process dummy NMEA data from GPS receiver
4   */
5  #include <string.h>
6  #include <stdio.h>
7  #include "lwgps/lwgps.h"
8
9  /* GPS handle */
10 lwgps_t hgps;
11
12 /**
13  * \brief      Dummy data from GPS receiver
14  */
15 const char
16 gps_rx_data[] = ""
17     "$GPRMC,183729,A,3907.356,N,12102.482,W,000.0,360.0,080301,015.5,E*6F\
↳r\n"
18     "$GPRMB,A,,,,,,,,,,,,,V*71\r\n"
19     "$GPGGA,183730,3907.356,N,12102.482,W,1,05,1.6,646.4,M,-24.1,M,,*75\r\
↳n"
20     "$GPGSA,A,3,02,,,07,,09,24,26,,,,,1.6,1.6,1.0*3D\r\n"
21     "$GPGSV,2,1,08,02,43,088,38,04,42,145,00,05,11,291,00,07,60,043,35*71\
↳r\n"
22     "$GPGSV,2,2,08,08,02,145,00,09,46,303,47,24,16,178,32,26,18,231,43*77\
↳r\n"
23     "$PGRME,22.0,M,52.9,M,51.0,M*14\r\n\r\n"
24     "$GPGLL,3907.360,N,12102.481,W,183730,A*33\r\n"
25     "$PGRMZ,2062,f,3*2D\r\n"
26     "$PGRMM,WGS84*06\r\n"
27     "$GPBOD,,T,,M,,*47\r\n"
28     "$GPRTE,1,1,c,0*07\r\n"
29     "$GPRMC,183731,A,3907.482,N,12102.436,W,000.0,360.0,080301,015.5,E*67\
↳r\n"
30     "$GPRMB,A,,,,,,,,,,,,,V*71\r\n";
31
32 int
33 main() {
34     /* Init GPS */
35     lwgps_init(&hgps);
36
37     /* Process all input data */
38     lwgps_process(&hgps, gps_rx_data, strlen(gps_rx_data));
39
40     /* Print messages */

```

(continues on next page)

(continued from previous page)

```

41     printf("Valid status: %d\r\n", hgps.is_valid);
42     printf("Latitude: %f degrees\r\n", hgps.latitude);
43     printf("Longitude: %f degrees\r\n", hgps.longitude);
44     printf("Altitude: %f meters\r\n", hgps.altitude);
45
46     return 0;
47 }

```

5.4.2 Parse received data from interrupt/DMA

Second example is a typical use case with interrupts on embedded systems. For each received character, application uses `ringbuff` as intermediate buffer. Data are later processed outside interrupt context.

Note: For the sake of this example, application *implements* interrupts as function call in *while loop*.

Listing 5: Example of buffer

```

1  #include "lwgps/lwgps.h"
2  #include "lwrp/lwrp.h"
3  #include <string.h>
4
5  /* GPS handle */
6  lwgps_t hgps;
7
8  /* GPS buffer */
9  lwrp_t hgps_buff;
10 uint8_t hgps_buff_data[12];
11
12 /**
13  * \brief      Dummy data from GPS receiver
14  * \note      This data are used to fake UART receive event on microcontroller
15  */
16 const char
17 gps_rx_data[] = ""
18     "$GPRMC,183729,A,3907.356,N,12102.482,W,000.0,360.0,080301,015.5,E*6F\r\n"
19     "$GPRMB,A,,,,,,,,,,,,,V*71\r\n"
20     "$GPGGA,183730,3907.356,N,12102.482,W,1,05,1.6,646.4,M,-24.1,M,,*75\r\n"
21     "$GPGSA,A,3,02,,,07,,09,24,26,,,,,1.6,1.6,1.0*3D\r\n"
22     "$GPGSV,2,1,08,02,43,088,38,04,42,145,00,05,11,291,00,07,60,043,35*71\r\n"
23     "$GPGSV,2,2,08,08,02,145,00,09,46,303,47,24,16,178,32,26,18,231,43*77\r\n"
24     "$PGRME,22.0,M,52.9,M,51.0,M*14\r\n"
25     "$GPGLL,3907.360,N,12102.481,W,183730,A*33\r\n"
26     "$PGRMZ,2062,f,3*2D\r\n"
27     "$PGRMM,WGS84*06\r\n"
28     "$GPBOD,,T,,M,,*47\r\n"
29     "$GPRTE,1,1,c,0*07\r\n"
30     "$GPRMC,183731,A,3907.482,N,12102.436,W,000.0,360.0,080301,015.5,E*67\r\n"
31     "$GPRMB,A,,,,,,,,,,,,,V*71\r\n";

```

(continues on next page)

```
32 static size_t write_ptr;
33 static void uart_irqhandler(void);
34
35 int
36 main() {
37     uint8_t rx;
38
39     /* Init GPS */
40     lwgps_init(&hgps);
41
42     /* Create buffer for received data */
43     lwrb_init(&hgps_buff, hgps_buff_data, sizeof(hgps_buff_data));
44
45     while (1) {
46         /* Add new character to buffer */
47         /* Fake UART interrupt handler on host microcontroller */
48         uart_irqhandler();
49
50         /* Process all input data */
51         /* Read from buffer byte-by-byte and call processing function */
52         if (lwrb_get_full(&hgps_buff)) { /* Check if anything in buffer now */
53             while (lwrb_read(&hgps_buff, &rx, 1) == 1) {
54                 lwgps_process(&hgps, &rx, 1); /* Process byte-by-byte */
55             }
56         } else {
57             /* Print all data after successful processing */
58             printf("Latitude: %f degrees\r\n", hgps.latitude);
59             printf("Longitude: %f degrees\r\n", hgps.longitude);
60             printf("Altitude: %f meters\r\n", hgps.altitude);
61             break;
62         }
63     }
64
65     return 0;
66 }
67
68 /**
69  * \brief      Interrupt handler routing for UART received character
70  * \note      This is not real MCU, it is software method, called from main
71  */
72 static void
73 uart_irqhandler(void) {
74     /* Make interrupt handler as fast as possible */
75     /* Only write to received buffer and process later */
76     if (write_ptr < strlen(gps_rx_data)) {
77         /* Write to buffer only */
78         lwrb_write(&hgps_buff, &gps_rx_data[write_ptr], 1);
79         ++write_ptr;
80     }
81 }
```

5.4.3 Distance and bearing

Library provides calculation of distance and bearing between 2 coordinates on earth. This is useful if used with autonomous devices to understand in which direction device has to move to reach end point while knowing start coordinate.

Listing 6: Distance and bearing calculation

```
1  #include "lwgps/lwgps.h"
2
3  /* Distance and bearing results */
4  lwgps_float_t dist, bear;
5
6  /* New York coordinates */
7  lwgps_float_t lat1 = 40.685721;
8  lwgps_float_t lon1 = -73.820465;
9
10 /* Munich coordinates */
11 lwgps_float_t lat2 = 48.150906;
12 lwgps_float_t lon2 = 11.554176;
13
14 /* Go from New York to Munich */
15 /* Calculate distance and bearing related to north */
16 lwgps_distance_bearing(lat1, lon1, lat2, lon2, &dist, &bear);
17 printf("Distance: %f meters\r\n", (float)dist);
18 printf("Initial bearing: %f degrees\r\n", (float)bear);
19
20 /* Go from Munich to New York */
21 /* Calculate distance and bearing related to north */
22 lwgps_distance_bearing(lat2, lon2, lat1, lon1, &dist, &bear);
23 printf("Distance: %f meters\r\n", (float)dist);
24 printf("Initial bearing: %f degrees\r\n", (float)bear);
```


L

- LWGPS_CFG_DOUBLE (*C macro*), 22
- LWGPS_CFG_STATEMENT_GPGGA (*C macro*), 22
- LWGPS_CFG_STATEMENT_GPGSA (*C macro*), 22
- LWGPS_CFG_STATEMENT_GPGSV (*C macro*), 23
- LWGPS_CFG_STATEMENT_GPGSV_SAT_DET (*C macro*), 23
- LWGPS_CFG_STATEMENT_GPRMC (*C macro*), 23
- LWGPS_CFG_STATEMENT_PUBX (*C macro*), 23
- LWGPS_CFG_STATEMENT_PUBX_TIME (*C macro*), 23
- LWGPS_CFG_STATUS (*C macro*), 22
- lwgps_distance_bearing (*C++ function*), 19
- lwgps_float_t (*C++ type*), 18
- lwgps_init (*C++ function*), 19
- lwgps_is_valid (*C macro*), 17
- lwgps_process (*C++ function*), 19
- lwgps_process_fn (*C++ type*), 18
- lwgps_sat_t (*C++ struct*), 20
- lwgps_sat_t::azimuth (*C++ member*), 20
- lwgps_sat_t::elevation (*C++ member*), 20
- lwgps_sat_t::num (*C++ member*), 20
- lwgps_sat_t::snr (*C++ member*), 20
- lwgps_speed_t (*C++ enum*), 18
- lwgps_speed_t::lwgps_speed_fpm (*C++ enumerator*), 19
- lwgps_speed_t::lwgps_speed_fps (*C++ enumerator*), 19
- lwgps_speed_t::lwgps_speed_kph (*C++ enumerator*), 18
- lwgps_speed_t::lwgps_speed_kps (*C++ enumerator*), 18
- lwgps_speed_t::lwgps_speed_mipm (*C++ enumerator*), 19
- lwgps_speed_t::lwgps_speed_mips (*C++ enumerator*), 18
- lwgps_speed_t::lwgps_speed_mph (*C++ enumerator*), 19
- lwgps_speed_t::lwgps_speed_mpk (*C++ enumerator*), 19
- lwgps_speed_t::lwgps_speed_mpm (*C++ enumerator*), 18
- lwgps_speed_t::lwgps_speed_mps (*C++ enumerator*), 18
- lwgps_speed_t::lwgps_speed_smph (*C++ enumerator*), 19
- lwgps_speed_t::lwgps_speed_sp100m (*C++ enumerator*), 19
- lwgps_speed_t::lwgps_speed_sp100y (*C++ enumerator*), 19
- lwgps_speed_t::lwgps_speed_spk (*C++ enumerator*), 19
- lwgps_speed_t::lwgps_speed_spm (*C++ enumerator*), 19
- lwgps_statement_t (*C++ enum*), 18
- lwgps_statement_t::STAT_CHECKSUM_FAIL (*C++ enumerator*), 18
- lwgps_statement_t::STAT_GGA (*C++ enumerator*), 18
- lwgps_statement_t::STAT_GSA (*C++ enumerator*), 18
- lwgps_statement_t::STAT_GSV (*C++ enumerator*), 18
- lwgps_statement_t::STAT_RMC (*C++ enumerator*), 18
- lwgps_statement_t::STAT_UBX (*C++ enumerator*), 18
- lwgps_statement_t::STAT_UBX_TIME (*C++ enumerator*), 18
- lwgps_statement_t::STAT_UNKNOWN (*C++ enumerator*), 18
- lwgps_t (*C++ struct*), 20
- lwgps_t::altitude (*C++ member*), 21
- lwgps_t::clk_bias (*C++ member*), 22
- lwgps_t::clk_drift (*C++ member*), 22
- lwgps_t::course (*C++ member*), 21
- lwgps_t::date (*C++ member*), 21
- lwgps_t::dop_h (*C++ member*), 21
- lwgps_t::dop_p (*C++ member*), 21
- lwgps_t::dop_v (*C++ member*), 21
- lwgps_t::fix (*C++ member*), 21
- lwgps_t::fix_mode (*C++ member*), 21
- lwgps_t::geo_sep (*C++ member*), 21
- lwgps_t::hours (*C++ member*), 21

lwgps_t::is_valid (C++ member), 21
lwgps_t::latitude (C++ member), 21
lwgps_t::leap_sec (C++ member), 22
lwgps_t::longitude (C++ member), 21
lwgps_t::minutes (C++ member), 21
lwgps_t::month (C++ member), 21
lwgps_t::satellites_ids (C++ member), 21
lwgps_t::sats_in_use (C++ member), 21
lwgps_t::sats_in_view (C++ member), 21
lwgps_t::sats_in_view_desc (C++ member),
21
lwgps_t::seconds (C++ member), 21
lwgps_t::speed (C++ member), 21
lwgps_t::tp_gran (C++ member), 22
lwgps_t::utc_tow (C++ member), 22
lwgps_t::utc_wk (C++ member), 22
lwgps_t::variation (C++ member), 21
lwgps_t::year (C++ member), 22
lwgps_to_speed (C++ function), 20