# **LwSHELL**

**Tilen MAJERLE** 

# **CONTENTS**

1	Features	3
2	Requirements	5
3	Contribute	7
4	License	9
5	Table of contents	11
	5.1 Getting started	11
	5.2 User manual	15
	5.3 API reference	16
	5.4 Examples and demos	23
	5.5 Changelog	24
	5.6 Authors	
In	ex ·	27

Welcome to the documentation for version latest-develop.

 $LwSHELL\ is\ lightweight\ dynamic\ memory\ manager\ optimized\ for\ embedded\ systems.$ 

Download library Getting started Open Github Donate

CONTENTS 1

2 CONTENTS

# **ONE**

# **FEATURES**

- Lightweight commands shell for embedded systems
- Platform independent and very easy to port
  - Development of library under Win32 platform
- Written in C language (C99)
- No dynamic allocation, maximum number of commands assigned at compile time
- Highly configurable
- Simple help-text with *cmd* -*v* option
- User friendly MIT license

# TWO

# **REQUIREMENTS**

- C compiler
- Less than 5kB of non-volatile memory

# **THREE**

# **CONTRIBUTE**

Fresh contributions are always welcome. Simple instructions to proceed:

- 1. Fork Github repository
- 2. Respect C style & coding rules used by the library
- 3. Create a pull request to develop branch with new features or bug fixes

### Alternatively you may:

- 1. Report a bug
- 2. Ask for a feature request

### **FOUR**

### **LICENSE**

#### MIT License

Copyright (c) 2024 Tilen MAJERLE

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

10 Chapter 4. License

**FIVE** 

### TABLE OF CONTENTS

# 5.1 Getting started

Getting started may be the most challenging part of every new library. This guide is describing how to start with the library quickly and effectively

## 5.1.1 Download library

Library is primarly hosted on Github.

You can get it by:

- · Downloading latest release from releases area on Github
- Cloning main branch for latest stable version
- Cloning develop branch for latest development

#### **Download from releases**

All releases are available on Github releases area.

#### **Clone from Github**

### First-time clone

This is used when you do not have yet local copy on your machine.

- Make sure git is installed.
- Open console and navigate to path in the system to clone repository to. Use command cd your\_path
- Clone repository with one of available options below
  - Run git clone --recurse-submodules https://github.com/MaJerle/lwshell command to clone entire repository, including submodules
  - Run git clone --recurse-submodules --branch develop https://github.com/MaJerle/ lwshell to clone development branch, including submodules
  - Run git clone --recurse-submodules --branch main https://github.com/MaJerle/ lwshell to clone latest stable branch, including submodules
- Navigate to examples directory and run favourite example

#### Update cloned to latest version

- Open console and navigate to path in the system where your repository is located. Use command cd your\_path
- Run git pull origin main command to get latest changes on main branch
- Run git pull origin develop command to get latest changes on develop branch
- Run git submodule update --init --remote to update submodules to latest version

**Note:** This is preferred option to use when you want to evaluate library and run prepared examples. Repository consists of multiple submodules which can be automatically downloaded when cloning and pulling changes from root repository.

### 5.1.2 Add library to project

At this point it is assumed that you have successfully download library, either cloned it or from releases page. Next step is to add the library to the project, by means of source files to compiler inputs and header files in search path.

*CMake* is the main supported build system. Package comes with the CMakeLists.txt and library.cmake files, both located in the lwshell directory:

- CMakeLists.txt: Is a wrapper and only includes library.cmake file. It is used if target application uses add\_subdirectory and then uses target\_link\_libraries to include the library in the project
- library.cmake: It is a fully configured set of variables. User must use include(path/to/library.cmake) to include the library and must manually add files/includes to the final target

Tip: Open library.cmake file and manually analyze all the possible variables you can set for full functionality.

If you do not use the *CMake*, you can do the following:

- Copy lwshell folder to your project, it contains library files
- Add lwshell/src/include folder to *include path* of your toolchain. This is where *C/C*++ compiler can find the files during compilation process. Usually using -I flag
- Add source files from lwshell/src/ folder to toolchain build. These files are built by *C/C*++ compiler. CMake configuration comes with the library, allows users to include library in the project as **subdirectory** and **library**.
- Copy lwshell/src/include/lwshell/lwshell\_opts\_template.h to project folder and rename it to lwshell\_opts.h
- · Build the project

### 5.1.3 Configuration file

Configuration file is used to overwrite default settings defined for the essential use case. Library comes with template config file, which can be modified according to the application needs. and it should be copied (or simply renamed in-place) and named lwshell\_opts.h

**Note:** Default configuration template file location: lwshell/src/include/lwshell/lwshell\_opts\_template. h. File must be renamed to lwshell\_opts.h first and then copied to the project directory where compiler include

paths have access to it by using #include "lwshell\_opts.h".

**Tip:** If you are using *CMake* build system, define the variable LWSHELL\_OPTS\_FILE before adding library's directory to the *CMake* project. Variable must contain the path to the user options file. If not provided and to avoid build error, one will be generated in the build directory.

Configuration options list is available available in the *Configuration* section. If any option is about to be modified, it should be done in configuration file

Listing 1: Template configuration file

```
/**
    * \file
                        lwshell_opts_template.h
2
                        Template config file
      \brief
3
6
    * Copyright (c) 2024 Tilen MAJERLE
    * Permission is hereby granted, free of charge, to any person
    * obtaining a copy of this software and associated documentation
    * files (the "Software"), to deal in the Software without restriction,
11
    * including without limitation the rights to use, copy, modify, merge,
12
    * publish, distribute, sublicense, and/or sell copies of the Software,
13
    * and to permit persons to whom the Software is furnished to do so,
    * subject to the following conditions:
15
    * The above copyright notice and this permission notice shall be
17
    * included in all copies or substantial portions of the Software.
    * THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND,
    * EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES
21
    * OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE
22
    * AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT
23
    * HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY,
24
    * WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING
25
    * FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR
26
    * OTHER DEALINGS IN THE SOFTWARE.
27
28
      This file is part of LwSHELL - Lightweight shell library.
29
30
    * Author:
                        Tilen MAJERLE <tilen@majerle.eu>
31
    * Version:
                        v1.2.0
32
   #ifndef LWSHELL_OPTS_HDR_H
34
   #define LWSHELL_OPTS_HDR_H
36
   /* Rename this file to "lwshell_opts.h" for your application */
37
38
    * Open "include/lwshell/lwshell_opt.h" and
```

(continues on next page)

(continued from previous page)

```
# copy & replace here settings you want to change values
#/
#endif /* LWSHELL_OPTS_HDR_H */
```

**Note:** If you prefer to avoid using configuration file, application must define a global symbol LWSHELL\_IGNORE\_USER\_OPTS, visible across entire application. This can be achieved with -D compiler option.

### 5.1.4 Minimal example code

To verify proper library setup, minimal example has been prepared. Run it in your main application file to verify its proper execution

Listing 2: Absolute minimum example

```
#include <string.h>
   #include "lwshell/lwshell.h"
   /* Command to get called */
   int32 t
   mycmd_fn(int32_t argc, char** argv) {
       printf("mycmd_fn called. Number of argv: %d\r\n", (int)argc);
       for (int32_t i = 0; i < argc; ++i) {</pre>
           printf("ARG[%d]: %s\r\n", (int)i, argv[i]);
       }
10
11
       /* Successful execution */
12
       return 0;
13
   }
14
15
   /* Example code */
16
   void
17
   example_minimal(void) {
       const char* input_str = "mycmd param1 \"param 2 with space\"\r\n";
19
20
       /* Init library */
21
       lwshell_init();
22
23
       /* Define shell commands */
24
       lwshell_register_cmd("mycmd", mycmd_fn, "Adds 2 integer numbers and prints them");
25
       /* User input to process every character */
27
       /* Now insert input */
29
       lwshell_input(input_str, strlen(input_str));
   }
31
```

### 5.2 User manual

#### 5.2.1 How it works

This section describes how library works from the basic perspective.

LwSHELL is designed to accept *computer-command-like* input, in format of cmdname param1 "param 2 with space", parse it properly and search for function callback that is assigned for specific cmdname.

Library starts processing input line on *line-feed* or *carriage-return* characters. It splits tokens by space character:

- Tokens must not include space character or it will be considered as multi-token input
- To use space character as token input, encapsulate character in double-quotes

#### **Command structure**

Every command has assigned dedicated name and must start with it. Application must take care to input exact command name since commands are case-sensitive, mycmd is a different command than Mycmd.

Command structure looks like:

- It must start with command name and has at least one (1) parameter, eg. mycommand. Command name is counted as first parameter
- It may have additional parameters split with *space* character
- Every input is parsed as string, even if parameter is string

Tip: To use space as an input, encapsulate it with double quotes, eg. mycmd param1 "param 1 has spaces"

#### Register command

Application must register command(s) to be used by the system. This can be done using lwshell\_register\_cmd() function which accepts *command name*, *command function* and optional *command description* 

### **Command description**

Every command can have assigned its very simple description text, know as *help text*. Description is later accessible with special command input that has 2 parameters in total and second is -h, cmdname -h.

#### **Data output**

To properly work with the library, application must input data to process by using lwshell\_input() function. Thanks to the library implementation, it is possible to get data feedback and be able to implement OS-like console.

To enable data-output feature, define your output callback function and assign it with lwshell\_set\_output\_fn() function.

Data outputs works on:

- Special characters for carriage return and line-feed
- Special character backspace that returns set of characters to implement backspace-like event on your output

5.2. User manual 15

- · Actual input character printed back for user feedback
- cmdname -h feature works to print simple help text

### 5.3 API reference

List of all the modules:

#### **5.3.1 LwSHELL**

### group LWSHELL

Lightweight shell.

#### **Defines**

#### LWSHELL\_ARRAYSIZE(x)

Get size of statically allocated array.

#### **Parameters**

• **x** – [in] Object to get array size of

#### Returns

Number of elements in array

#### lwshell\_init()

Initialize shell interface.

Note: It applies to default shell instance

#### Returns

lwshellOK on success, member of lwshellr\_t otherwise

#### lwshell\_set\_output\_fn(out\_fn)

Set output function to use to print data from library to user.

Note: It applies to default shell instance

### **Parameters**

•  $out_{fn}$  – [in] Output function to print library data. Set to NULL to disable the feature

### Returns

*lwshellOK* on success, member of *lwshellr\_t* otherwise

#### lwshell\_register\_cmd(cmd\_name, cmd\_fn, desc)

Register new command to shell.

**Note:** It applies to default shell instance

**Note:** Available only when *LWSHELL\_CFG\_USE\_DYNAMIC\_COMMANDS* is enabled

#### **Parameters**

- cmd\_name [in] Command name. This one is used when entering shell command
- cmd\_fn [in] Function to call on command match
- desc [in] Custom command description

#### Returns

lwshellOK on success, member of lwshellr\_t otherwise

#### lwshell\_input(in\_data, len)

Input data to shell processing.

Note: It applies to default shell instance

#### **Parameters**

- in\_data [in] Input data to process
- len [in] Length of data for input

#### **Returns**

lwshellOK on success, member of lwshellr\_t otherwise

#### lwshell\_register\_static\_cmds(cmds, cmds\_len)

Register new command to shell.

Note: It applies to default shell instance

Note: Available only when LWSHELL\_CFG\_USE\_STATIC\_COMMANDS is enabled

#### **Parameters**

- cmds [in] Array of const static commands. It can be from non-volatile memory
- cmds\_len [in] Length of array elements

### Returns

*lwshellOK* on success, member of *lwshellr\_t* otherwise

5.3. API reference 17

#### lwshell\_parse\_int(str)

Parse input string as integer

#### **Parameters**

• **str** – [in] String to parse

#### Returns

String parsed as integer

### lwshell\_parse\_double(str)

Parse input string as double

#### **Parameters**

• **str** – [in] String to parse

#### Returns

String parsed as double

### lwshell\_parse\_long(str)

Parse input string as long

#### **Parameters**

• **str** – [in] String to parse

#### Returns

String parsed as long

### lwshell\_parse\_long\_long(str)

Parse input string as long long

#### **Parameters**

• **str** – [in] String to parse

#### **Returns**

String parsed as long long

#### **Typedefs**

```
typedef int32_t (*lwshell_cmd_fn)(int32_t argc, char **argv)
```

Command function prototype.

#### Param argc

[in] Number of arguments

### Param argv

[in] Pointer to arguments

#### Return

0 on success, -1 otherwise

typedef void (\*lwshell\_output\_fn)(const char \*str, struct lwshell \*lwobj)

Callback function for character output.

### Param str

[in] String to output

#### Param lwobj

[in] LwSHELL instance

#### **Enums**

```
enum lwshellr_t
```

LwSHELL result enumeration.

Values:

enumerator lwshelloK = 0x00

Everything OK

enumerator lwshellERRPAR

Parameter error

enumerator lwshellERRMEM

Memory error

#### **Functions**

```
lwshellr_t lwshell_init_ex(lwshell_t *lwobj)
```

Initialize shell interface.

#### **Parameters**

**lwobj** – [in] LwSHELL object instance. Set to NULL to use default one

#### Returns

lwshellOK on success, member of lwshellr t otherwise

lwshellr\_t lwshell\_set\_output\_fn\_ex(lwshell\_t \*lwobj, lwshell\_output\_fn out\_fn)

Set output function to use to print data from library to user.

#### **Parameters**

- lwobj [in] LwSHELL object instance. Set to NULL to use default one
- out\_fn [in] Output function to print library data. Set to NULL to disable the feature

#### Returns

*lwshellOK* on success, member of *lwshellr\_t* otherwise

Register new command to shell.

**Note:** Available only when *LWSHELL\_CFG\_USE\_DYNAMIC\_COMMANDS* is enabled

#### **Parameters**

- lwobj [in] LwSHELL object instance. Set to NULL to use default one
- cmd\_name [in] Command name. This one is used when entering shell command

5.3. API reference 19

- cmd\_fn [in] Function to call on command match
- desc [in] Custom command description

#### Returns

lwshellOK on success, member of lwshellr\_t otherwise

lwshellr\_t lwshell\_input\_ex(lwshell\_t \*lwobj, const void \*in\_data, size\_t len)

Input data to shell processing.

#### **Parameters**

- lwobj [in] LwSHELL object instance. Set to NULL to use default one
- in\_data [in] Input data to process
- len [in] Length of data for input

#### Returns

lwshellOK on success, member of lwshellr t otherwise

 $lwshell_t = lwshell_t = lwsh$ 

Register new command to shell.

Note: Available only when LWSHELL\_CFG\_USE\_STATIC\_COMMANDS is enabled

#### **Parameters**

- lwobj [in] LwSHELL object instance. Set to NULL to use default one
- cmds [in] Array of const static commands. It can be from non-volatile memory.
- cmds\_len [in] Length of array elements

#### Returns

lwshellOK on success, member of lwshellr\_t otherwise

### struct lwshell\_cmd\_t

#include <lwshell.h> Shell command structure.

#### **Public Members**

#### lwshell\_cmd\_fn **fn**

Command function to call on match

#### const char \*name

Command name to search for match

#### const char \*desc

Command description for help

#### struct lwshell\_t

#include <lwshell.h> LwSHELL main structure.

#### **Public Members**

```
lwshell_output_fn out_fn
    Optional output function
char buff[LWSHELL_CFG_MAX_INPUT_LEN + 1]
    Shell command input buffer
size_t buff_ptr
   Buffer pointer for input
int32_t argc
   Number of arguments parsed in command
char *argv[LWSHELL_CFG_MAX_CMD_ARGS]
    Array of pointers to all arguments
lwshell_cmd_t dynamic_cmds[LWSHELL_CFG_MAX_DYNAMIC_CMDS]
    Shell registered dynamic commands
size_t dynamic_cmds_cnt
    Number of registered dynamic commands
const lwshell_cmd_t *static_cmds
    Pointer to an array of static commands
size_t static_cmds_cnt
   Length of status commands array
```

### 5.3.2 Configuration

This is the default configuration of the middleware. When any of the settings shall be modified, it shall be done in dedicated application config lwshell\_opts.h file.

**Note:** Check *Getting started* for guidelines on how to create and use configuration file.

```
group LWSHELL_OPT
LwSHELL options.
```

5.3. API reference 21

#### **Defines**

#### LWSHELL\_MEMSET (dst, val, len)

Memory set function.

**Note:** Function footprint is the same as memset

#### LWSHELL\_MEMCPY (dst, src, len)

Memory copy function.

**Note:** Function footprint is the same as memcpy

#### LWSHELL\_CFG\_USE\_DYNAMIC\_COMMANDS

Enables 1 or disables 0 dynamic command register with *lwshell\_register\_cmd* or *lwshell\_register\_cmd\_ex* functions.

#### See also:

LWSHELL CFG USE STATIC COMMANDS

Note: Set to 1 by default for backward compatibility

#### LWSHELL\_CFG\_USE\_STATIC\_COMMANDS

Enables 1 or disables 0 static command registration.

When enabled, a single register call is used where application can pass constant array of the commands and respective callback functions.

This allows RAM reduction as lookup tables can be stored in the non-volatile memory

#### See also:

 $LWSHELL\_CFG\_USE\_DYNAMIC\_COMMANDS$ 

Note: Set to 0 by default for backward compatibility

#### LWSHELL\_CFG\_MAX\_CMDS

Maximum number of different dynamic registered commands.

Deprecated:

**Warning:** Deprecated and replaced with *LWSHELL\_CFG\_MAX\_DYNAMIC\_CMDS* 

#### LWSHELL\_CFG\_MAX\_DYNAMIC\_CMDS

Maximum number of different dynamic registered commands.

**Note:** Used only when *LWSHELL\_CFG\_USE\_DYNAMIC\_COMMANDS* is enabled

#### LWSHELL\_CFG\_MAX\_INPUT\_LEN

Maximum characters for command line input.

This includes new line character and trailing zero. Commands longer than this are automatically discarded

#### LWSHELL\_CFG\_MAX\_CMD\_NAME\_LEN

Maximum characters for command name in bytes.

Note: Used only when LWSHELL CFG USE DYNAMIC COMMANDS is enabled

#### LWSHELL\_CFG\_MAX\_CMD\_ARGS

Maximum number of parameters accepted by command.

Number includes command name itself

#### LWSHELL\_CFG\_USE\_OUTPUT

Enables 1 or disables 0 output function to print data from library to application.

This is useful to give library feedback to user

#### LWSHELL\_CFG\_USE\_LIST\_CMD

Enables 1 or disables 0 generic 'listcmd' command to list of registered commands.

LWSHELL\_CFG\_USE\_OUTPUT must be enabled to use this feature

# 5.4 Examples and demos

Various examples are provided for fast library evaluation on embedded systems. These are prepared and maintained for 2 platforms, but could be easily extended to more platforms:

- WIN32 examples, prepared as Visual Studio Community projects
- ARM Cortex-M examples for STM32, prepared as STM32CubeIDE GCC projects

Warning: Library is platform independent and can be used on any platform.

### 5.4.1 Example architectures

There are many platforms available today on a market, however supporting them all would be tough task for single person. Therefore it has been decided to support (for purpose of examples) 2 platforms only, WIN32 and STM32.

#### **WIN32**

Examples for WIN32 are prepared as Visual Studio Community projects. You can directly open project in the IDE, compile & debug.

#### **STM32**

Embedded market is supported by many vendors and STMicroelectronics is, with their STM32 series of microcontrollers, one of the most important players. There are numerous amount of examples and topics related to this architecture.

Examples for STM32 are natively supported with STM32CubeIDE, an official development IDE from STMicroelectronics

You can run examples on one of official development boards, available in repository examples.

# 5.5 Changelog

```
# Changelog
## Develop
## 1.2.0
- Change license year to 2022
- Update code style with astyle
- Add `.clang-format` draft
- Add option for statically allocated commands array (improvement for small devices w/_
→little memory)
- Add option to disable dynamic commands allocation (default value)
## v1.1.1
- Split CMakeLists.txt files between library and executable
- Fix wrongly interpreted backspace character
## v1.1.0
- Add support for `listcmd` to print all registered commands
- Optimize code and remove unnecessary brackets
## v1.0.0
- First stable release
- Fix wrong parsing of command names
```

(continues on next page)

(continued from previous page)

## v0.1.0

- First release

### 5.6 Authors

List of authors and contributors to the library

```
Tilen Majerle <tilen.majerle@gmail.com>
Tilen Majerle <tilen@majerle.eu>
jnz86 <jumpifnotzero@gmail.com>
Ballen7 <33672651+Ballen7@users.noreply.github.com>
ballen7 <ballen@neuronicworks.com>
Brandon <ballen@neuronicworks.com>
Hagai Gold <hagaigold@gmail.com>
```

5.6. Authors 25

### **INDEX**

```
L
                                                 lwshell_t::static_cmds (C++ member), 21
                                                 lwshell_t::static_cmds_cnt (C++ member), 21
LWSHELL_ARRAYSIZE (C macro), 16
                                                 lwshellr_t(C++enum), 19
LWSHELL_CFG_MAX_CMD_ARGS (C macro), 23
                                                 lwshellr_t::lwshellERRMEM(C++ enumerator), 19
LWSHELL_CFG_MAX_CMD_NAME_LEN (C macro), 23
                                                 lwshellr_t::lwshellERRPAR (C++ enumerator), 19
LWSHELL_CFG_MAX_CMDS (C macro), 22
                                                 lwshellr_t::lwshellOK (C++ enumerator), 19
LWSHELL_CFG_MAX_DYNAMIC_CMDS (C macro), 22
LWSHELL_CFG_MAX_INPUT_LEN (C macro), 23
LWSHELL_CFG_USE_DYNAMIC_COMMANDS (C macro), 22
LWSHELL_CFG_USE_LIST_CMD (C macro), 23
LWSHELL_CFG_USE_OUTPUT (C macro), 23
LWSHELL_CFG_USE_STATIC_COMMANDS (C macro), 22
lwshell\_cmd\_fn(C++type), 18
lwshell_cmd_t (C++ struct), 20
lwshell\_cmd\_t::desc(C++ member), 20
lwshell\_cmd\_t::fn(C++ member), 20
lwshell\_cmd\_t::name(C++ member), 20
lwshell_init (C macro), 16
lwshell_init_ex (C++ function), 19
lwshell_input (C macro), 17
lwshell_input_ex (C++ function), 20
LWSHELL_MEMCPY (C macro), 22
LWSHELL_MEMSET (C macro), 22
lwshell_output_fn (C++type), 18
lwshell_parse_double (C macro), 18
lwshell_parse_int (C macro), 17
lwshell_parse_long (C macro), 18
lwshell_parse_long_long (C macro), 18
lwshell_register_cmd (C macro), 16
lwshell_register_cmd_ex (C++ function), 19
lwshell_register_static_cmds (C macro), 17
lwshell_register_static_cmds_ex (C++ function),
        20
lwshell_set_output_fn (C macro), 16
lwshell_set_output_fn_ex (C++ function), 19
lwshell_t (C++ struct), 20
lwshell_t::argc(C++ member), 21
lwshell_t::argv(C++ member), 21
lwshell_t::buff(C++ member), 21
lwshell_t::buff_ptr(C++ member), 21
lwshell_t::dynamic\_cmds(C++ member), 21
lwshell_t::dynamic_cmds_cnt (C++ member), 21
```

 $lwshell_t::out_fn (C++ member), 21$